

anda seat

PACKAGE CONTENTS

1. Chair Backrest X 1
2. Chair Seatbase X 1
3. Armrests (2) X 1
4. Backrest Recline Lever X 1
5. 5-Star Wheel Base X 1
6. M8 Allen Key X 1
7. M6 Allen Key X 1
8. Casters (Wheels) X 5
9. Side Covers X 2
10. Hydraulic Piston X 1
11. M8 Screws X 8
12. M6 Screws X 2
13. Lumbar Support X 1
14. Neck Pillow X 1

For French & Assembly Video



CAUTION: Do not adjust the recline lever until the backrest has been securely installed (Step 8). Doing so may cause the backrest to spring forward.



1 Remove all parts from the box while taking care to avoid the backrest recline lever and backrest bracket. Check if there are any missing parts.



2 Lay out the foam sheets found in the packaging on a flat surface. Place the wheelbase upside down on top of the foam and invert the 5 casters.



USAGE INFORMATION



BACKREST RECLINE
Pull the lever FULLY and lean back slowly until desired angle is achieved. Then slowly return the lever to its starting position. Ensure the lever locks back in place.



TILT TENSION
Turn the knob clockwise to loosen the rocking tension of the chair, and clockwise to tighten. Adjust according to your weight.



ARMRESTS ADJUSTMENT
The distance between armrests can be adjusted. Loosen the M8 screws on the bottom of the armrests and move to the desired position. Then tighten to secure.



CONVENTIONAL TILT MECHANISM
Right lever (left side): Pull up to adjust height. Push towards to lock the rocking mode.



MULTI-FUNCTIONAL TILT MECHANISM
Right lever (left side): Pull up to adjust height. Left lever: Flip up to unlock the rocking mode. Flip down to lock the rocking mode.



ARMRESTS
Press and hold each bottom and adjust accordingly. To adjust the angle, simply push the top portion of the armrests in either direction.

Safety Information



90° Comfortable work mode
120° Reading mode
140° Watching movie mode
160° Taking a rest mode

360°
Swivel



-  **360 Degree Swivel**
Find the correct and comfortable position
-  **Knee Tilt**
Rock back and forth between 90 and 160 degrees
Lock at 90 degree upright position
-  **Seat Height Adjustable**
For multi-tasking convenience

Lift the Angle Adjusting Lever Up Allowing Your Weight Push The Backrest Backward Until Desired Angle Is Reached