



True Wireless Earbuds

Focus on your workouts better

Advanced Active Noise Cancellation Technology



What is Active Noise Cancellation?

ANC helps block out lower frequency sounds in places like busy streets, when in traffic, or when riding the subway, buses, trains, planes and so on, and helps you focus on what you want to hear.

How do I activate ANC mode?

Please press and hold the RIGHT earbud for 2 seconds to turn on/off ANC mode.

Tips:

ANC is usable only in dual listening mode. Please select suitable ear tips to enjoy a better experience when using ANC mode.



Fast & Stable Connections

Built-in Bluetooth 5.0 chipset helps your earbuds to transmit faster and be more stable.



Smart Touch Controls

Easily take hands-free calls, skip tracks, activate voice assistant with just one tap of your earbud.




Waterproof and Sweatproof

Our waterproof coating efficiently protects your earbuds from sweat or splashes, perfect for running, workouts and more.

Features a Customizable and Comfortable Fit

Our ergonomically designed earbuds come with 3 sizes of ear tips that offer a comfortable fit and superior sound isolation



Please Note:

- Please put your earbuds into the charging case when the battery has run out, you may need to reopen your case cover to activate your earbuds again to resume charging.

- To prevent the rusting of the charging pins, please regularly clean your earbuds with a dry, soft cotton swab or cloth.